
Wait for start
start
mode = 1?
Yes
No
CMD18
READ_MULTIPLE_BLOCKS
Read block
???_done?
No
Yes
CMD12
STOP_TRANSMISSION
Activate config_n
cfg_init_n low?
No
Yes
Deactivate config_n
cfg_init_n high?
No
Yes